

Digitech GSP21, GSP21 and GSP21 Legend battery installation instructions

English



You need the following tools to install the battery:

- A screwdriver PZ2
- A torx-head screwdriver T-15

WARNING!!!

- a) Note that you will lose all your presets by replacing the battery!
If you want to keep them, consider a bulk MIDI dump or individual program dump.
- b) As with any electronic equipment, make sure you are static-grounded before opening and operating on the unit. Take care of all ESD protection rules.

Installation instructions:

1. Switch off the unit and pull all plugs.
2. Make sure to remove the mains power cable.
3. Remove the upper 2 rear-panel screws.
4. Remove the screws on the top of the unit.
5. Remove the upper torx-bolt (T-15 torx head) at the front plate.
6. Remove the cover panel.
7. Locate the Battery at the lower left corner on the mainboard.
8. Remove the old battery from the battery holder.
9. Mount the new battery in the holder. Pay close attention to the orientation of the battery.
The plus contact must point to the back panel of the unit as shown in the picture above.
If you mount the battery in the wrong direction your unit will be destroyed immediately and will not hold the settings anymore.
10. Close up the unit. Don't leave your tools inside the unit.
11. Now you have to reset your unit:
Connect power cord, switch off the unit, switch on the unit WHILE pressing down the "UTILITY" button, a message appears at the display "Are you sure? – Press ↑ For Yes", release the "UTILITY" button, press (and release) the "PARAMETER ↑" button, The display reads "Factory PresetsLoading....". Now wait until the unit is ready.
12. The battery replacement is now complete. Switch off your unit and then switch it back on.